


AcuIOM

Universal I/O Module

QUICK SETUP GUIDE



ACCUEVERGY

Table of Contents

1. Overview	1
2. Operating Environment	1
3. Appearance and Dimensions	2
4. Module Installation	3
5. Power	3
6. Terminals and Wiring	4
6.1 Wiring Guidelines.....	5
6.2 Circuit Diagrams - I/O Wiring Connections.....	6
7. Basic Configuration	7
8. Communication	7
8.1 Ethernet Communication.....	8
8.2 RS485 Communication.....	8
8.3 USB Communication	8
9. I/O Functions	9
10. Specifications	9
11. Functions List	12

MODELS

AcuIOM-1: 8 Analog Input, 2 Analog Output

AcuIOM-2: 16 Analog Input, 4 Analog Output

AcuIOM-3: 14 Digital Input, 2 Digital Output, 2 Relay Output

AcuIOM-4: 28 Digital Input, 4 Digital Output, 2 Relay Output

Important Safety Notice

Please read this document carefully prior to installation, operation, and maintenance of the AcuLOM. Accuenergy is not responsible or liable for any damage or injury caused by improper installation and/or operation.

- Installation and maintenance must be performed by qualified personnel in accordance with local electrical codes.
- Prior to wiring and repair, the equipment must be de-energized and grounded. Always de-energize and ground the equipment before wiring or maintenance.

The following symbols can be found either in this document or on the product.



WARNING ALERT: Indicates a hazardous circumstance which may result in severe injury or death..



NOTE: Provides additional information before action shall be taken by the user.

Legal Notice

This AcuLOM Quick Setup Guide provides informational and operational guidance regarding the use of the device. While effort has been made to ensure the accuracy, reliability, and completeness of the information at the time of publication, Accuenergy assumes no responsibility for any errors, omissions, or misunderstandings in this document and reserves the right to modify its content at any time without prior notice.

Users should verify with Accuenergy or their authorized local representative that the document in use is the latest version and strictly adhere to the installation, operation, and maintenance procedures specified herein. Accuenergy shall not be held liable for any damages or consequences resulting from improper use or failure to comply with the provisions of this document.

This manual may not be altered or reproduced in whole or in part by any means without the expressed written consent of Accuenergy.

1. Overview

Follow these steps to commission the module:

1. Mount the module on a DIN rail.
2. Connect the control power.
3. Depending on the model, wire the supported I/O terminals, which may include AI, AO, DI, DO, and RO.
4. Connect to the communication interface using RS485, Ethernet, or USB.
5. Turn on the power and check the status LEDs.
6. Connect using the Acuvision 2 software.

Factory default communication settings allow for immediate access.

2. Operating Environment



WARNING ALERT

Ensure that the following specifications are met. Failure to do so may affect accuracy, impair system function, damage hardware, or pose safety risks.

PARAMETER	SPECIFICATION
Location	Indoor Use
Installation Environment	Dry and Dust-Free Location
Electromagnetic Conditions	Avoid Strong Electromagnetic Interference
Operating Temperature	-25 °C to +70 °C (-13 °F to 158 °F)
Operating Humidity	0 % to 95 % (Non-Condensing)
Maximum Operating Altitude	2000 m
Pollution Degree	2

3. Appearance and Dimensions


The AcuIOM is a compact, DIN rail mounted I/O device designed for installation inside electrical panels or control cabinets.

The AcuIOM I/O module enclosure includes:


1. Removable plug-in terminal blocks
2. Front-mounted status LEDs
3. Rear-mounted DIN rail clips

Refer to the diagrams for overall dimensions. The physical appearance and terminal layout may vary depending on the AcuIOM model.

FRONT VIEW



SIDE VIEW



4. Module Installation

The AcuIOM is designed to be mounted on a standard 35mm DIN rail.

DIN Rail Mounting Procedure


1. Pull out the two mounting clips at the bottom of the device.
2. Place the module onto the DIN rail.
3. Push the clips back until a click is heard.

Ensure the device is firmly seated and stable.



NOTE

Maintain sufficient clearance around the module for wiring and removal.
Route power and communication cables separately to reduce EMI.



5. Power



WARNING ALERT

Disconnect all power sources before wiring. Improper wiring may result in equipment damage or personal injury.

Ensure correct polarity when wiring power terminals.

The AcuIOM uses low-voltage DC control power.

PARAMETER	SPECIFICATION
Voltage Range	12-36 VDC
Maximum Power Consumption	6 W
Supply Type	LPS / SELV

TERMINAL	DESCRIPTION	MODEL	
1	Power (+ / -)	Control Power Input	All Models
2	RO	Relay Outputs	AcuIOM-3, AcuIOM-4
3	RS485 (A / B / S)	Modbus RTU, BACnet MS/TP	All Models
4	USB	Power Input or USB Modbus RTU	All Models
5	ETH1 / ETH2	Ethernet (Modbus TCP/IP, BACnet/IP)	All Models
6	AI	Analog Inputs	AcuIOM-1, AcuIOM-2
7	AO	Analog Outputs	AcuIOM-1, AcuIOM-2
8	DI	Digital Outputs	AcuIOM-3, AcuIOM-4
9	DO	Digital Outputs	AcuIOM-3, AcuIOM-4

Terminal-by-terminal wiring details are provided in the User Manual.

6.1 Wiring Guidelines



WARNING ALERT

Disconnect all power sources before wiring. Improper wiring may result in equipment damage or personal injury.



NOTE


- Disconnect all power sources before wiring. Improper wiring may result in equipment damage or personal injury
- Use appropriate cable sizes as specified
- Separate high-noise and signal wiring

TERMINAL	SCREW TORQUE
Power (+ / -) RS485 (A / B / S) AI, DI, DO, AO	0.2 N · m
RO	0.66 N · m

All I/O channels are galvanically isolated as specified.

TERMINAL	FUNCTION	TERMINAL TYPE	TERMINAL APERTURE
Power (+, -)	Power Input Port	Plug-In Type	1.5 mm ²
A, B, S	RS485 Communication Port	Plug-In Type	1.5 mm ²
USB	Power Input Port for MCU or USB Modbus RTU	Plug-In Type	Dedicated Line
ETH1, ETH2	Ethernet	Plug-In Type	Dedicated Line
AI	Sensor Input of Voltage or Current Signal	Plug-In Type	1.5 mm ²
DI	Used As Status Input or Pulse Counter	Plug-In Type	1.5 mm ²
AO	Protocol-Controlled Output, Converted into Voltage or Current Signal	Plug-In Type	1.5 mm ²
DO	Protocol-Controlled Output	Plug-In Type	1.5 mm ²
RO	Protocol-Controlled Output	Plug-In Type	2.5 mm ²

6.2 Circuit Diagrams - I/O Wiring Connections




7. Basic Configuration

The AcuIOM does not require front-panel configuration. Basic setup and verification are performed using the Acuvision 2 software. Use default communication settings for initial connection.

8. Communication

The AcuIOM supports multiple communication methods.



8.1 Ethernet Communication

The AcuIOM features dual 10/100 Mbps Ethernet Ports (non-independent) and supports Modbus TCP/IP and BACnet/IP protocols. It also allows for direct connection to Acuvue 2 software using Modbus TCP/IP.

DEFAULT ETHERNET SETTINGS

IP Address	192.168.1.254
Subnet Mask	255.255.255.0
Gateway	192.168.1.1

8.2 RS485 Communication

The AcuIOM supports Modbus RTU and BACnet MS/TP protocols, with terminals provided for A (+), B (-), and S (Shield) connections. Use a USB-RS485 converter cable when connecting to a PC.

DEFAULT RS485 SETTINGS

Slave Address	1
Baud Rate	19,200
Parity	None1 (No Parity, One Stop Bit)

8.3 USB Communication

The USB port in AcuIOM may be used for powering the AcuIOM and supports USB Modbus RTU communication. The USB is intended primarily for commissioning and testing.

DEFAULT USB SETTINGS

Slave Address	1
Baud Rate	19,200
Parity	None1 (No Parity, One Stop Bit)

9. I/O Functions

This section provides a high-level summary of the I/O capabilities

Digital Input (DI)	External Input Voltage up to 160 VAC/DC Support Status Monitoring and Pulse Counting
Digital Output (DO)	External supply up to 250 VAC/DC Maximum current: 100mA
Relay Output (RO)	Form A Relay Contact Maximum Switching: 250 VAC/30 VDC Maximum Current: 5A (Resistive)
Analog Input (AI)	Voltage or Current Input Accuracy: 0.2%
Analog Output (AO)	Voltage or Current Output Accuracy: 0.5%

Scaling, mapping, and control behavior are configured using the Acuvision 2 software.

10. Specifications

COMMUNICATION

RS485

Baud Rate	1200-115200 bps
Protocols	Modbus RTU, BACnet MS/TP

ETHERNET

Type	10/100 Mbps
Protocols	Modbus TCP/IP

POWER SUPPLY

Universal	LPS or SELV
-----------	-------------

LOW VOLTAGE DC CONTROL POWER

Operating Range	12~36 VDC
Maximum Burden	6 W

DIGITAL INPUT

LOW VOLTAGE DC CONTROL POWER

Maximum External Power Supply	160 VAC / DC
Maximum Frequency	50 Hz with a 50% Duty Cycle (10 ms ON, 10 ms OFF)
On-State Voltage	Above 15 VDC
Off-State Voltage	Below 5 VDC
Isolation Voltage	2500 VAC

DIGITAL OUTPUT

LOW VOLTAGE DC CONTROL POWER

External Power Supply	0~250 VAC/DC
Maximum Current	100 mA
Maximum Output Frequency	25 Hz
Isolation Voltage	2500 VAC

RELAY OUTPUT

Universal	1 Form A
-----------	----------

LOW VOLTAGE DC CONTROL POWER

Maximum Switching Voltage	250 VAC, 30 VDC
Maximum Load Current	5A (Resistive)
Isolation Voltage	2500 VAC

ANALOG INPUT

LOW VOLTAGE DC CONTROL POWER

External Power Supply	0-20 mA / 0-10 VDC
Accuracy	0.2 %
Isolation Voltage	500 VDC

ANALOG OUTPUT

LOW VOLTAGE DC CONTROL POWER


External Power Supply	0-20 mA / 0-10 VDC
Accuracy	0.5 %
Isolation Voltage	500 VDC

OPERATING ENVIRONMENT

Operating Temperature	-25 °C to 70 °C -13 °F to 158 °F
Storage Temperature	-40 °C to 85 °C -40 °F to 185 °F
Relative Humidity	0 % to 95 %
Altitude	0~2000 m
Pollution Degree	2
Location/Mounting	Indoor Use Only

11. Function List

PART	FUNCTION
LED	Power: Power Indicator; Run: Running Indicator
Timer	Real Time Clock (Year, Month, Date, Hour, Minute, Second)
SOE log	Loop Recording of 200 Entries
Communication Ports	RS485 Modbus RTU, BACnet MS/TP
	Ethernet Modbus TCP/IP
	USB Modbus RTU
DI	Used as Status Input or Pulse Counter
DO	Protocol-Controlled Output
AI	Sensor Input of Voltage or Current Signal
AO	Protocol-Controlled Output, Converted into Voltage or Current signal.
RO	Protocol-Controlled Output
USB	Power Supply for MCU
Configuration Function	Flexibly Adapt Settings Based on On-Site Applications.



ACCUEVERGY

Accuenergy Inc.

Los Angeles - Toronto - Pretoria

North America Toll Free: 1-877-721-8908

Web: www.accuenergy.com

Email: marketing@accuenergy.com

Revision Date: June 2026 Version: 1.0.0

Specs Subject To Change Without Notice.